

Remember - Signal Energy:

- The Energy of a signal is defined by:

$$E_g = \int_{-\infty}^{\infty} |g(t)|^2 dt \quad * \text{ If } g(t) \text{ is complex, then } |g(t)|^2 \text{ is equivalent to } \rightarrow |g(t)|^2 = g(t) \cdot g^*(t)$$

← complex conjugate


- If we know our Fourier Transform, we can also relate Energy to the Signal Spectrum

$$E_g = \int_{-\infty}^{\infty} |g(t)|^2 dt = \frac{1}{2\pi} \int_{-\infty}^{\infty} |G(\omega)|^2 d\omega \quad \text{Parseval's Theorem}$$

Parseval's Theorem - The total energy of a signal calculated in the time domain is equal to the total energy calculated in the frequency domain.

Example ① : Parseval's Theorem

Consider the signal  $g(t) = e^{-\alpha t} u(t)$  for ( $\alpha > 0$ ), calculate its signal energy in both time and frequency domains.



$$|U(t)|^2 \rightarrow 1 \text{ for } t > 0 \\ 0 \text{ for } t \leq 0$$

Step ①: Find  $E_g$  in the time-domain

$$E_g = \int_{-\infty}^{\infty} |g(t)|^2 dt = \int_{-\infty}^{\infty} |e^{-\alpha t} u(t)|^2 dt = \int_0^{\infty} e^{-2\alpha t} dt$$

$$E_g = -\frac{1}{2\alpha} e^{-2\alpha t} \Big|_0^{\infty} = -\frac{1}{2\alpha} [e^{-\infty} - e^0] = -\frac{1}{2\alpha} [0 - 1]$$

$E_g = \frac{1}{2\alpha}$ Time - Domain Energy
------------------------------------------------

Example ① : Parseval's Theorem - ContinuedStep ②: Find  $E_g$  in the frequency-domain

$$E_g = \frac{1}{2\pi} \int_{-\infty}^{\infty} |G(\omega)|^2 d\omega$$

$$g(t) = e^{-\alpha t} u(t) \rightarrow G(\omega) = \frac{1}{\alpha + j\omega}. (\text{when } \alpha > 0)$$

$$E_g = \frac{1}{2\pi} \int_{-\infty}^{\infty} \left| \frac{1}{\alpha + j\omega} \right|^2 d\omega \neq |\alpha + j\omega|^2 = (\alpha + j\omega)(\alpha - j\omega) \\ \neq |\alpha + j\omega|^2 = \alpha^2 + \omega^2$$

$$E_g = \frac{1}{2\pi} \int_{-\infty}^{\infty} \frac{1}{\alpha^2 + \omega^2} d\omega \quad \neq \int \frac{1}{\alpha^2 + \omega^2} d\omega = \frac{1}{\alpha} \arctan\left(\frac{\omega}{\alpha}\right)$$

$$E_g = \frac{1}{2\pi} \int_{-\infty}^{\infty} \frac{1}{\alpha^2 + \omega^2} d\omega = \frac{1}{2\pi} \cdot \frac{1}{\alpha} \arctan\left(\frac{\omega}{\alpha}\right) \Big|_{-\infty}^{+\infty}$$

$$E_g = \frac{1}{2\pi\alpha} \left[ \frac{\pi}{2} - \left( -\frac{\pi}{2} \right) \right] = \frac{1}{2\pi\alpha} [\cancel{\pi}] = \frac{1}{2\alpha}$$

$$E_g = \frac{1}{2\alpha} \quad \text{Frequency Domain}$$

$$E_g = \frac{1}{2\alpha} \quad \text{Time-Domain Energy}$$

## Energy Spectral Density - How Is Energy Distributed Across Frequency?

- We can think of the **signal Energy ( $E_g$ )** as the result of energies contributed by all **spectral components**

$$E_g = \frac{1}{2\pi} \int_{-\infty}^{\infty} |G(\omega)|^2 d\omega$$


Resulting <sup>↑</sup>  
 Total  
 Energy

Energy of each individual  
 Frequency Component  
 "Spectrum"

- We say that **ESD** is the energy per unit bandwidth of the spectral components of  $g(t)$  centered at frequency ( $\omega$ )

$$\Psi(\omega) = |G(\omega)|^2 \quad \text{and} \quad E_g = \frac{1}{2\pi} \int_{-\infty}^{\infty} \Psi(\omega) d\omega$$

- We can also call **ESD** the Spectral Contribution



- If  $x(t)$  and  $y(t)$  are the input and output of LTI system

$$Y(\omega) = h(\omega) X(\omega)$$

$$|Y(\omega)|^2 = |h(\omega)|^2 |X(\omega)|^2$$


$$\Psi_y(\omega) = |h(\omega)|^2 \Psi_x(\omega)$$

$\Psi(\omega)$  - ESD

The ESD of an output signal is the multiplication of  $|h(\omega)|^2$  and the ESD of the system input signal

Essential Bandwidth

- The essential bandwidth is the range of frequencies where most of the signal's energy is held.
  - ↳ "most" depends on the application (could be 90%, 95%, etc)
  - ↳ The percentage is with respect to your overall energy



- Using the picture above, if  $G(\omega)$  is a low pass signal and  $E_B$  is the Energy from  $-2\pi B$  to  $2\pi B$ , then

$$E_B = \frac{1}{2\pi} \int_{-2\pi B}^{2\pi B} |G(\omega)|^2 d\omega$$

$$\frac{E_B}{E_g} = 0.9$$

- These two equations help you find  $B$  if you know all other information

## Correlation Function


- Correlation is the measurement of **similarity** between two signals

$$R_{12} = \int_{-\infty}^{\infty} x_1(t) x_2(t-\tau) dt$$

- This function has two use cases, to find the **Time Delay** between two signals or to examine the **Similarity** of two functions

↳ If  $\tau$  is zero  $\rightarrow$  Peak Correlation

- In a **RADAR** example,  $\tau$  can be thought of as a **range variable**:



- This Correlation Function is extremely similar to Energy and ESD

$$\Psi_g(\tau) = \int_{-\infty}^{\infty} g^*(t) g(t+\tau) dt$$

Auto Correlation

$$x_1(t) = x_2(t)$$



Cross Correlation  
 $x_1(t) \neq x_2(t)$

↑ Time Delay  
 \* more complex \*



- In this class, we will mostly deal with Auto Correlation

Correlation Example

- Original Signal





- Channel Noise



- Resulting Signal

↳ Very hard to extract any good info!



Random Noise &  
low average  
distribution

Auto  
Correlation

Allows us  
to examine  
meaningful  
Similarities

- Remember, Auto - Correlation and ESD → Very Similar

$$\hat{\psi}_g(\tau)$$

Auto - Correlation

$$\hat{\psi}(w)$$

ESD

]


Transform Pair

- Both of these are wanting to examine a  $|G(w)|^2$  signal!

Power Spectral Density - How Is My Power Distributed Across FrequencyRecall that :

$$E_g = \int_{-\infty}^{\infty} |g(t)|^2 dt$$

- Let's say I have some truncated signal  $g_T(t)$ , shown below:



$$E_{gT} = \int_{-\infty}^{\infty} |g_T(t)|^2 dt = \frac{1}{2\pi} \int_{-\infty}^{\infty} |G_T(\omega)|^2 d\omega$$

\* Remember → Spectral Density means the contributions @ certain frequency

- We say that Power Spectral Density (PSD) is given as:

$$S_g(\omega) = \lim_{T \rightarrow \infty} \frac{|G_T(\omega)|^2}{T} \quad (\text{PSD})$$

\* As  $T$  increases,  $|G_T(\omega)|^2$  also increases

\* Since  $P_g$  is finite (power signal), the increase rates of  $T$  and  $|G_T(\omega)|^2$  must be the same

$$P_g = \frac{1}{2\pi} \int_{-\infty}^{\infty} S_g(\omega) d\omega = \frac{1}{2\pi} \int_{-\infty}^{\infty} \lim_{T \rightarrow \infty} \frac{|G_T(\omega)|^2}{T} d\omega$$

Auto-Correlation of Power Signal

$$R_g(\tau) = \lim_{T \rightarrow \infty} \frac{1}{T} \int_{-\infty}^{\infty} g^*(t) g(t + \tau) dt$$

$$R_g(\tau) = \frac{1}{T_0} \int_0^{T_0} g^*(t) g(t + \tau) dt$$

Periodic Functions and  
what we will use  
the most in our course

- As with ESD previously, the auto-correlation function and PSD are a **Transform Pair**

$$R_g(\tau) \leftrightarrow S_g(\omega)$$

:-)

- Remember, we use transform pairs to help simplify!

Example ②: PSD vs. Power

Find the power spectral density (PSD) and the power of the function  $x(t) = A \cos(\omega_0 t + \Theta)$  Theta

\* Try and work this problem for next class \*

\* Next class we will work examples and I  
will assign Homework ① \*